

Vertical Multistage Centrifugal In-line Pumps Spare Parts

VPC-VPS 45

Vertical Pumps



POS.	PARTS NAME
11	Discharge part
12	Chamber, upper
+24	Neck ring
+25	Neck ring retainer
13	Chamber, middle with bearing ring
+24	Neck ring
+25	Neck ring retainer
14	Middle bearing
+15	Bearing fixed ring
16	Bearing sleeve
+17	Bearing
18	Impeller
18A	Impeller
+19	Bush
+20	Neck ring base
21	Split cone
22	Split cone nut
30	Strap retainer
36	Pump head
37	Pump shaft
38	Spring washer
39	Clamp washer
40	"Hexagon socket head screw"
41	Bearing internal sleeve
42	Bearing outer sleeve
43	Coupling Assembly (ψ24) 2, 3 HP
	Coupling Assembly (ψ28) 4, 5.5 HP
	Coupling Assembly (ψ38) 7.5, 10 HP
	Coupling Assembly (ψ42) 15, 20, 25 HP
	Coupling Assembly (ψ48) 30 HP
+73	Hexagon socket head screw (M8) - 2HP~5.5HP
	Hexagon socket head screw (M10) - 7.5HP~40HP
47	Strap
48	Pump casing
53	Motor stool (4, 5.5 HP)
	Motor stool (7.5, 10 HP)
	Motor stool (15, 30 HP)
	Motor stool (40 HP)
	Motor stool (60 HP)
54	Coupling guard (2 ~ 10HP)
	Coupling guard (15 ~ 40HP)
57	Shaft seal
+66	O-ring (EPDM)
59	Flange
61	Base (Flange)
62	Base plate (Flange)
64	Air vent screw
65	Plug
69	Hexagon socket head screw
70	Hexagon socket head screw
71	Washer
74	Screw
75	Screw
76	O-ring
77	Nut
78	Washer
79	Nut
80	Disc spring
81	Staybolt
82	O-ring (EPDM)
86	Retaining ring
87	Washer
88	Hexagon socket head screw
90	Washer
92	Screw

